



Installation Instructions  
for  
Transfer Case Skid Plate  
for  
1995-2004 Toyota Tacoma or 1996-2002 Toyota 4Runner

Thank you for purchasing your new Skid Row Offroad transfer case skid plate. It is designed to give you peace of mind while traversing even the toughest trails.

Your skid plate package should come complete with the following parts:

1. (1) Transfer Case Skid Plate
2. (4) 3/8-16 UNC x .75" Self-Tapping Hex Head Bolts
3. (2) 3/8-16 UNC x 3.0" Carriage Head Bolt
4. (2) 3/8-16 UNC Hex Nut
5. (2) 3/8" Lock Washers
6. (6) 3/8 Flat Washers

**Step 1:** Remove the factory "skid plate" from the transfer case.

**Step 2:** Lift the new transfer case skid plate into place as shown to the right. There should be existing holes in the chassis cross-member. You may want to use a floor jack to hold the skid plate in position.

**Step 3:** Install two 3/8-16 UNC x 3.0" carriage head bolts, flat washers, lock washers, and nuts. Center the skid plate on the chassis and tighten the bolts.

**Step 4:** Drill four 5/16" holes into the chassis using the holes in the skid plate as a guide.

**Step 5:** Install the four 3/8-16 UNC x .75" self-tapping hex head bolts with flat washers.

**Step 6:** You're ready to hit the trail!



We hope you enjoy your new Skid Row Offroad transfer case skid plate!

Sincerely,

**The Staff at SFK Manufacturing, LLC**

**SFK Manufacturing, LLC**  
PO Box 306, Shermans Dale, PA 17090  
Phone 717-701-8315  
Fax 717-701-8316

[www.SkidRowOffroad.com](http://www.SkidRowOffroad.com)